


# **Unit V:**

## **Micro/Nano Measurement systems**



# Course Content

**Unit I: Introduction to Mechanical Micro Machining:** Principle Micro Machining techniques, micro turning, micro milling, micro drilling, micro grinding, micro Tool geometry and tool materials, cutting forces and measurement, micro tool and tooling management.

**Unit II: Components of micro manufacturing systems:** Micro linear stage, rotary stage, air spindle, air bearings, magnetic bearings, servo motors and micro actuators, micro positioning systems, Micro robots, micro grippers, micro parts handling systems - selection criteria

**Unit III: Non conventional micro machining technique:** Micro EDM, Ion Beam machining, Laser micro machining, Laser Assisted Mechanical Micro Machining, Abrasive micro machining, Electron beam machining – process mechanics, capabilities and Applications

**Unit IV: Micro forming:** Micro forming processes- ultra fine punching, imprinting, extrusion, incremental forming, micro forming of sheet metals, micro-deep drawing.

**Unit V: Micro/Nano Measurement systems:** Micro sensors, laser measurement systems, capacitance sensors, micro optical sensors, feedback sensors, 2D and 3D surface profiling.

# Text Books and References

## 10. Text Books:

1. Joseph Mc Geough, Micromaching of Engineering Materials, Marcel Dekker Inc, New York, 2002.
2. Yi Qin, Micro-Manufacturing Engineering and Technology, Elsevier Inc., Oxford, UK, 2010.

## 11. References:


1. V. K. Jain, Introduction to Micromachining, Narosa Publishing House Pvt Ltd, New Delhi, 2010.
2. J. Paulo Davim and Mark J. Jackson, Nano and Micromachining, John Wiley & Sons, London, UK., 2013.
3. P.C. Pandey and H. S. Shan, Modern Machining Processes, Tata McGraw Hill, New Delhi, 2009.
4. Richard S. Muller, Microsensors, New York: IEEE Press, 1991.
5. Frank Vollertsen, Micro Metal Forming, Springer-Verlag, Berlin Heidelberg, Germany, 2013.

# What is Metrology?

**Metrology is the science of measurement**



- *The Science Behind Quality Control on a Manufacturing Shop Floor*
  
- Metrology is the science of measurement, embracing both experimental and theoretical determinations at any level of uncertainty in any field of science and technology. "International Bureau of Weights and measurements (BIPM)"




# Need of Measurements:

- ✓ To ensure that the products supplied to the customer are within the agreed specifications.
- ✓ To monitor the process performance.
- ✓ To ensure that the purchased materials are confirm to the purchaser's specifications.
- ✓ To meet the interchangeability concept.
- ✓ To evaluate the possibility of rework of defective parts.
- ✓ To exclude sources of errors and deficiency in the process
- ✓ To establish limit gauging. To achieve reverse engineering.
- ✓ To augment the reputation of manufacturer and to help him to become a world class manufacturer

# Modern Inspection Devices

1. Contact Inspection devices
2. Non-contact Inspection devices.




# Measurements

- Surface Characteristics
- Dimensions
- Form

Surface texture is the combination of fairly short wavelength deviations of a surface from the nominal surface.

**Roughness:** Roughness includes the finest (shortest wavelength) irregularities of a surface.


**Waviness:** Waviness includes the more widely spaced (longer wavelength) deviations of a surface from its nominal shape.



Ref: ASME B46.1. Surface texture (surface roughness, waviness, and lay), 1995.

# Micro – Nano Surfaces and devices

- Surface metrology plays an important role in the functioning of machined, etched, molded parts in different market areas like
  - automotive/aerospace
    - bearing surfaces
    - shafts
    - dynamic seals
  - high-brightness LED
  - solar
  - Semiconductor
  - medical device markets




*“If you can’t measure it, you  
can’t make it”*

# Applications




## Wear-resistant coatings

TiN, TiC, DLC, WC  
Cutting tools



## Biomedical

Tablets and pills  
Implants and Tissues




## Semiconductors

Low K materials  
Interconnects  
Passivation layers



## Optical components

Window Glass  
Lenses  
Optical coatings




## Automotive & Aerospace

Paints and intermediate layers  
Windows Engine components

# Surface Finish - 3D parameter

## 1. Arithmetic mean height (Sa)




This is a 3D parameter expanded from the roughness (2D) parameter Ra. It expresses the average of the absolute values of Z(x,y) in the measured area.

These are commonly-used parameters. The influence of a single injury on the measurement value becomes extremely small, so stable results can be obtained.

## Roughness (3D) parameter


### 2. Maximum height (Sz)



This is a 3D parameter expanded from the roughness (2D) parameter Rz. It expresses the sum of the maximum value of peak height Zp and the maximum value of valley depth Zy on the surface within the measured area

They are used for evaluation of gloss and luster, surface strength, surface treatability, frictional force, electrical contact resistance, etc.


### 3. Maximum peak height (Sp)



This is a 3D parameter expanded from the roughness (2D) parameter Rp. It expresses the maximum value peak height Zp on the surface in the measured area.

These are often used for evaluation of frictional force and electrical contact resistance.


#### 4. Maximum valley depth (Sv)



This is a 3D parameter expanded from the roughness (2D) parameter Rv. It expresses the maximum value valley depth Zv on the surface in the measured area.

These are often used for evaluation of surface strength and corrosion resistance.

## 5. Root mean squared height (Sq)



This is a 3D parameter expanded from the roughness (2D) parameter Rq. It expresses the root mean squared of  $Z(x,y)$  in the measured area. It is equivalent to the average mean squared of the measured region on the three-dimensional display diagram when valleys have been changed to high peaks by squaring.

Evaluation methods using Rq are often used when expanded into 3D.






Fig: 3D surface profile of a Nano surface (courtesy AMETEK, Precitech Inc.)

## Attributes used for Characterization of 3D areal surface texture




# Profile characteristics in Micro Components



<http://rtec-instruments.com/profilometer.htm>

# Surface Measurement Technology



WSI - White-light Scanning Interferometry  
PSI - Phase Shifting Interferometry



SEM- Scanning Electron Microscopy  
SPM - Scanning Probe Microscopy

# Types of Profilometer

- Contact Profilometer
  - ✓ Stylus Profilometer
  - ✓ Atomic Force Microscopy (AFM)
  - ✓ Scanning Tunneling Microscopy
- Non-Contact Profilometer
  - Optical Methods
    - ✓ Vertical Scanning Interferometry
    - ✓ Phase - Shifting Interferometry
    - ✓ Differential Interference Contrast Microscopy

# 3D profiling






Michigan Metrology

Since 1994...

1000's of projects for 100's of clients






*Brake Rotor Surface*



Title: Sensor Wear

Note:



# Key Technology

- AFM: Highest lateral resolution with multiple modes and applications
- 3D Microscopy using WLI: Highest vertical resolution, non-contact high-speed 3D measurements
- Stylus: Low noise contact profiling with excellent measurement repeatability



## Atomic Force Microscopy

Nanoscale characterization of electrical, magnetic, compositional and material properties



## Optical Profiling


Non-contact 3D measurement of surface texture and roughness



## Stylus Profiling

Measure thin film step heights, stress and surface texture


# Specific Height and Lateral Ranges



*Ref:*

[www.bruker.co](http://www.bruker.co)


# Optical profiler Basic principle




**Optical Path Difference (OPD)** - difference in optical path lengths that beams travel in Reference and Test arms.

# Principle of Interferometry

- Difference in optical paths will cause a difference in phase
- Interference will be constructive at some points, destructive at others, forming an interferogram
- Two Techniques
  - Phase Shifting Interferometry (PSI)
  - Vertical Scanning Interferometry (VSI)






- Scan special objective in a predefined fashion to change optical path between sample and reference
- CCD camera captures the intensity changes over multiple frames
- Best focus determined from captured Intensity - phase calculated from the fringes or COM of signal envelope used to build height information

# Phase Shifting Interferometry(PSI)


- Piezoelectric transducer (PZT) linearly moves the reference surface
- A small, known amount to cause a phase shift between the test and reference beams
- The intensity of the resulting interference pattern at many different relative phase shifts, and then converts the intensity to wave front (phase) data by integrating the intensity data.



Ref:

# Vertical scanning Interferometry (VSI)

- Light reflected from a reference mirror combines with light reflected from a sample to produce interference fringes.
- System measures the **degree of fringe modulation**, or **coherence**, instead of the phase of the interference fringes



Ref:

# Coherence

- Two wave sources are perfectly coherent if they have a constant phase difference and the same frequency, and the same waveform. Coherence is an ideal property of waves that enables stationary (i.e. temporally and spatially constant) interference.




Figure 1: The amplitude of a single frequency wave as a function of time  $t$  (red) and a copy of the same wave delayed by  $\tau$  (blue). The coherence time of the wave is infinite since it is perfectly correlated with itself for all delays  $\tau$ . [11]:118

# Compressions PSI Vs VSI

## Phase Shifting Interferometry (PSI)

Narrow bandwidth filtered

Phase-shift at a single focus point – the objective doesn't move

Processes phase data from the intensity signal to calculate surface heights

160nm

$3\text{A}^0$

## Vertical scanning Interferometry (VSI)

Neutral density filter for white light

Vertically scans – the objective actually moves through focus

Processes fringe modulation data from the intensity signal to calculate surface heights

1mm (Range )

3nm (Vertical resolution)

*Ref:*

[www.braker.co](http://www.braker.co)

*m*

**W**  
**L**




# Stylus Profiler


**Stylus Profiler:** Collects data from the sample surface “Real Profile”

**Total Profile:** Unfiltered data produced by the stylus profiler

**Primary Profile:** Data after the short cut-off filter is applied (cut-off spatial frequency of  $\lambda_s$  to remove noise).




# Atomic Force Microscope



- 3-dimensional topography.
- Roughness measurements for chemical mechanical polishing.
- Analysis of microscopic phase distribution in polymers.
- Mechanical and physical property measurements for thin films.
- Imaging of sub micron phases in metals.
- Defect imaging in MEMS failure analysis.
- Inspection of Mechanical, Material and Electrical Properties.

# Atomic Force Microscope

- Feedback loop maintains constant deflection (force) of AFM cantilever
- Constant contact between the tip and sample surface facilitates:
  - • High resolution imaging
  - • Fast scanning speeds / fast data acquisition times



# Atomic Force Microscope (AFM)


- It is a scanned-proximity probe microscopes
- AFM do not use lenses, so the size of the probe rather than diffraction effects generally limits their resolution
- AFM is being applied to studies of phenomena such as abrasion, adhesion, cleaning, corrosion, etching, friction, lubrication, plating, and polishing






# Atomic Force Microscope ...


- The Atomic Force Microscope is being used to solve processing and materials problems in a wide range of technologies:
  - Electronics
  - Telecommunications
  - Biology
  - Chemistry
  - Automotive
  - Aerospace and
  - Energy industries

# Structure of AFM







**Fig: Schematic diagram of the different modes of AFM operation**




**Fig: Profile of a surface measured using AFM**

# Images taken by AFM



# Scanning Probe Microscope

- Electron beam is focused in to a small spot, electro magnetically raster scanned across it.
- Images are focused by collecting the secondary electrons generated by the impact of impinging electron beams by detecting back scattered electrons, or by detecting the X-rays generated.
- Different aspects including morphology, composition etc. are characterized.




# Scanning Electron Microscope (SEM)

- The Scanning Electron Microscope (SEM) is a microscope that uses electrons rather than light to form an image. There are many advantages to using the SEM instead of a light microscope
- The first modern scanning electron microscope, constructed by D. McMullan in the Cambridge University Engineering Laboratory in 1951
- The SEM has a large depth of field, which allows a large amount of the sample to be in focus at one time

# Scanning Electron Microscope (Contd.)

- The SEM also produces images of high resolution, which means that closely spaced features can be examined at a high magnification
- Preparation of the samples is relatively easy since most SEMs only require the sample to be conductive
- The combination of higher magnification, larger depth of focus, greater resolution, and ease of sample observation makes the SEM one of the most heavily used instruments in research areas today





# Scanning Electron Microscope



# Working Principle of SEM (Contd.)

- SEM uses electrons instead of light to form an image. A beam of electrons is produced at the top of the microscope by heating of a metallic filament
- The electron beam follows a vertical path through the column of the microscope. It makes its way through electromagnetic lenses which focus and direct the beam down towards the sample
- Once it hits the sample, other electrons (**backscattered or secondary**) are ejected from the sample. Detectors collect the secondary or backscattered electrons, and convert them to a signal that is sent to a viewing screen similar to the one in an ordinary television, producing an image

# Image taken by SEM




# Scanning Tunnelling Microscope

- If a conducting surface is brought within 1 nm of the tip, tunneling current will be induced
- which is used for getting the topography of the surface

## Modes of Operation:

1. Constant Current Mode
2. Constant Height Mode





# Scanning Tunneling Microscope


- Conceived in 1920's but first developed in 1982 by G. Binning in IBM Zurich
- Lateral resolution capable of resolving protruding atoms
- Vertical resolution is 0.01 nm
- Operate in vacuum, oil, liquid nitrogen and water
- Applications in micro-topography of precision finished surfaces, microlithography

# Operating Principle

- Quantum tunneling effect
- Electrons instead of bouncing pass through and current can be sensed
- Tunneling current is a function of local density of states




# Electron Tunneling




## Electron tunneling

- Quantum mechanical principle
- Conductive sample to metal tip  $\sim$  a few Å
- Small voltage applied ( $< 4V$ )
- 0.01 nA-50 nA current output by electron tunneling






# Metrological Scanning Probe Microscopy

## mSPM concept



# mSPM



# Confocal Microscope




Fig. 5. Principle of laser confocal microscopy






Fig. 6. Image fiber LED confocal microscope

- It uses a high intensity LED to project light through an image fiber bundle onto the work surface.
- The fiber bundle consists of 80000 fibers with about  $150\mu\text{m}$  in diameter each.
- The hexagonal grid pattern of the fiber bundle projected onto the work surface can be treated as a structural light.
- In the collected image frame the grey level change of the pixels is proportional to the distance out of focal plane of the probe

# 3D profiling






Michigan Metrology

Since 1994...

1000's of projects for 100's of clients






*Brake Rotor Surface*



Title: Sensor Wear

Note:




# Form Measurement


- Straightness
- Flatness
- Roundness
- Cylindricity
- Sphericity

# Straightness —


## EXAMPLE



## MEANING





CROSS SECTION THE POINT CLOUD AND BEST FIT A LINE TO THE RESULTING POINTS. THEN COLOR MAP THE LINE TO THE POINTS FOR A STRAIGHTNESS REPORT





# Flatness □

## EXAMPLE




## MEANING



BEST FIT A SURFACE TO THE POINT CLOUD AND COLOR MAP THE RESULT, GIVING YOU A FLATNESS REPORT





# *Circularity (Roundness) ○*

## EXAMPLE



## MEANING

{ .002  
WITHIN .002 WIDE TOL ZONE  
THIS FEATURE MUST BE CIRCULAR




SURFACE PERIPHERY AT ANY CROSS SECTION PERPENDICULAR TO THE AXIS  
MUST BE WITHIN THE SPECIFIED TOLERANCE OF SIZE AND MUST LIE  
BETWEEN TWO CONCENTRIC CIRCLES, ONE HAVING A RADIUS .002 LARGER  
THAN THE OTHER.

(ABOVE SIZES ARBITRARILY SELECTED FOR ILLUSTRATION)

CROSS SECTION THE POINT CLOUD AND BEST FIT A CIRCLE TO THE CROSS SECTION.  
THEN COLOR MAP THE POINT CLOUD TO THE CIRCLE FOR A CIRCULARITY REPORT.

# Cylindricity $\text{ø}$


## EXAMPLE





SYMBOL MEANING  
[ $\text{Ø} .003$ ] WITHIN .003 WIDE TOL ZONE  
THIS FEATURE MUST BE CYLINDRICAL

THE FEATURE MUST BE WITHIN THE SPECIFIED TOLERANCE OF SIZE AND MUST LIE BETWEEN TWO CONCENTRIC CYLINDERS (ONE HAVING A RADIUS .003 LARGER THAN THE OTHER).

## MEANING




BEST FIT A CYLINDER TO THE POINT CLOUD AND COLOR MAP THE RESULT FOR CYLINDRICITY REPORT




# Roundness and Cylindricity






# Measurement of Roundness Error

Separation method based on Harmonics in the form profile




Experimental arrangement for measurement of form error using capacitance sensor and roundness tester

# Profile of the artifact measured using roundness/form tester and capacitance sensor




Form profile  
obtained using  
roundness tester



Form profile obtained by  
capacitive sensor at 10KHz  
sampling frequency  
(Base circle radius : 10µm)

# Inspection of Freeform Surfaces



(a)


Design model



Click for more images

# Dimensional Measurement

# *Evolution in 3D measuring devices*




# 3D Laser Scanner

- 3D Laser Scanner CMM determines laser cloud point data samples from the object surface capturing work piece physical shape.
- A digital CAD model is made.
- A Laser Scanner is like spray painting of an object.
- Painting goes with laser scanner. hence difficult when sprayed deep.

- **Advantages:**


- Throughout fast
- Accurate
- Covers all the parts.
- It is repeatable
- It is a non contact
- User friendly based Windows System



3D Laser Scanning integrated with CMM System



**3D inspection of powdered metal components**



**Rolled steel defect inspection**




**Bearing seal inspection**



**Pre-weld assembly and weld bead inspection**


# Multi-sensor CMM

## Probes – Contact and Non-contact




## **Coordinate Measuring Machine (CMM)**

- A CMM consists of a constant probe that can be positioned in 3D space relative to the surface of a work part, and the x, y, and z coordinates of the probe can be accurately and precisely recorded to obtain dimensional data concerning the part geometry



# Classification of CMM - structures



- a.** Fixed Table Cantilever
- b.** Moving Bridge
- c.** Gantry
- d.** L Shaped Bridge
- e.** Fixed Bridge
- f.** Moving Table Cantilever
- g.** Column
- h.** Moving Ram Horizontal arm
- i.** Fixed Table Horizontal arm
- j.** Fixed Table Horizontal arm
- k.** Moving Table Horizontal arm

# Classification of CMM - structures



1) Cantilever



2) Bridge



3) Gantry



4) Column type




5) Horizontal arm type



6) Moving Bridge Type

## Multi sensor CMM (IITM)




**Bridge**

**Probe head  
(moves in X and  
Z direction)**

**Probes**

**Movable table  
(Moves in Y  
direction)**

**CMM  
Controller**



# Types of CMM Control



Manual Control




Manual drive with  
computer-assisted data  
processing




Motor drive with  
computer-assisted data  
processing

## About the Probe Tips

- CMMs generally gather their data by touching the workpiece with a probe (either a solid probe or an electronic touch-trigger probe) attached to the machine's measuring axis




## Various Types of Styli



a ) 5 way



b ) disc




c ) star



d) Cylindrical



e) hollow ball  
f) pointer



# TYPES OF PROBES

Two general categories

## 1. Contact (see figure)


Touch-trigger probe

Analog scanning probe




## 2. Noncontact

For inspection of printed circuit board, measuring a clay of wax model, when the object being measured would be deformed by the force of stylus

- laser probes
- video probes



# Principle of Touch Trigger Probe



# Advantages and Disadvantages of CMM


## Advantages

- The inspection rate is increased.
- Accuracy is more.
- Operators error can be minimized.
- Skill requirements of the operator is reduced.
- Reduced inspection fix Turing and maintenance cost.
- Reduction in calculating and recording time.
- Reduction in set up time.
- No need of separate go / no go gauges for each feature.
- Reduction of scrap and good part rejection.
- Reduction in off line analysis time.

## Disadvantages

- The table and probe may not be in perfect alignment.
- The probe may have run out.
- The probe moving in Z-axis may have some perpendicular errors.
- Probe while moving in X and Y direction may not be square to each other.
- There may be errors in digital system.

# Experimental setup



## XYZ linear stage



Travel range: 50 mm

Resolution: 0.156  $\mu\text{m}$  (1/8 step)

Min. incremental speed: 0.1 mm/s



## Data capturing device

- NI PCI 6250 DAQ system



# Evaluation of dimensional feature

## Evaluation of nominal width of the channel



- Least square line (LSL) is fitted for the edge coordinates of A and B (**Shunmugam, 1988**)



Ideal line reference to edge A

$$X'_{i(A)} = X_{i(A)} + (X_{N(B)} - X_{N(A)})$$

Measured width the channel

$$W_{k-measured} = X''_{i(A)} - X'_{i(A)}$$

## Evaluation of diameter of circular feature




- Based on isosceles trapezoid geometry construction
- $c_1, c_3$ -chord length


$$D = \frac{c_1 + c_3}{4} \sqrt{6 + \frac{c_1^2 + c_3^2}{c_1 c_3}}$$

# Experimental results

- Two specimens- Nominal width of channel (500 and 400 $\mu\text{m}$ ) and diameter of circular feature 1mm





Meso-scale channel feature with nominal width of 500  $\mu\text{m}$  on specimen 1



Meso-scale channel feature with nominal width of 400  $\mu\text{m}$  on specimen 2



## Measured output



# Experimental results

Evaluation of nominal width of the channel of the specimen 1  
(for channel number 1)\*

Section ( $s_i$ )	Position of Edge A coordinates $x_{i(A)}$ (mm)	Position of Edge B coordinates $x_{i(B)}$ (mm)	Ideal edge features using Least square method		Deviation from the ideal line of the edges		$X'_{i(A)}$ (mm)	Measured width of the channel $W_k$ (mm)
			$X_{i(A)}$ (mm)	$X_{i(B)}$ (mm)	$e_{i(A)}$ (mm)	$e_{i(B)}$ (mm)		
1	1.096	1.599	1.038	1.547	0.058	0.052	1.535	0.497
2	0.955	1.468	1.020	1.526	-0.065	-0.058	1.517	
3	0.948	1.451	1.002	1.505	-0.054	-0.054	1.499	
4	1.058	1.558	0.984	1.484	0.074	0.074	1.481	
5	0.954	1.448	0.966	1.463	-0.012	-0.015	1.463	





Measurement using optical profiler (Specimen 1 –channel 3)



# Comparison of results

Computed nominal width of the channel and circular features of the specimen 1


Channel number (k)	Measured width of the channel/slot features $W_k$ (mm)		% of deviation (compared to tool makers microscope)	% of deviation (compared to optical profiler)	
	Capacitive sensor	Optical methods			
		Tool makers microscope	Optical profiler		
Channel feature ( from section 1,2,3,4,5)					
1	0.497	0.483	0.493	2.90	
2	0.487	0.497	0.502	2.01	
3	0.491	0.502	0.496	2.19	
4	0.486	0.495	0.494	1.82	
5	0.477	0.482	0.484	1.04	



# Experimental results-Circular feature



SEM image of circular feature of specimen 1



$$C_1 = 0.714 \text{ mm} / C_2 = 0.719 \text{ mm}$$

Diameter of circular feature

Capacitive  
sensor



1.013 mm

Optical  
instrument

1.0127 mm

Tool makers  
microscope

0.970 mm



# Measurement of Micro components

## Nano CMM


- Inspection of micro components – Non contact inspection, nano CMM
- Tolerance Specification - ??



Prototype of Nano-CMM  
Measuring range - 10mm x 10mm x  
10mm  
Resolution - nanometer

# Computed Tomography


## Applications in industrial material inspection



Examples of radioscopy and CT inspection tasks in the aerospace business field.





3D visualization of a cone beam CT reconstruction of an aluminum steering gear case; dark spots represent small blowholes.



Digital tomosynthesis applied to a multilayer PCB

# Measurement of turbine blades.




Special blade inspection system with 450kV

RED – outside  
tolerance


# Inspection in Complex assemblies

Digital inspections of machined parts and assemblies for quality assurance purposes and supports both CMM machines and laser scanners.


- Digital quality checking saves time, effort, and money
- Perform simulation in a complete environment including parts, probes, fixtures and machines.
- Gauge quality of machined parts and assemblies, enabling first article inspection



# Computer Aided Virtual Environment



**Designers are able to experience and judge virtual 3-D interiors in the 'Design Cave' (Computer Aided Virtual Environment)**



**Surface quality inspection in the light chamber**




**Orientation check before pick  
and place operation**



**Extrusion geometry  
inspection**


# Large Scale Metrology

# *Laser Trackers*



# White Light Scanner

- Operating principle. Structured light is projected (a series of lines) onto the surface. There is a known angle and distance between the projector and the camera(s). This allows triangulation to be used to calculate the surface points allowing several million surface points created in a few seconds.



White Light Scanner